

<b>IT</b>	<b>EN</b>	<b>FR</b>	<b>NL</b>	<b>DE</b>	<b>ES</b>	<b>PT</b>
MANUALE TECNICO	TECHNICAL MANUAL	MANUEL TECHNIQUE	TECHNISCHE HANDLEIDING	TECHNISCHES HANDBUCH	MANUAL TÉCNICO	MANUAL TÉCNICO

Errata corrige Manuale tecnico cod. 2G40001275  
 Corrigenda for Technical manual code 2G40001275  
 Corrections Manuel technique réf. 2G40001275  
 Correcties vanaf Technische handleiding code 2G40001275  
 Fehlerberichtigung zu Technisches Handbuch code 2G40001275  
 Correcciones Manual técnico còd. 2G40001275  
 Errata do Manual técnico còd. 2G40001275



- |   |   |
|---|---|
| (IT) Pag. 8: configurazioni tasti capsense    | (DE) Seite 8: konfiguration der CapSense-Tasten   |
| (EN) Page 8: capsense key configuration       | (ES) Pág. 8: configuración de las teclas CapSense |
| (FR) Page 8 : configurations touches Capsense | (PT) Pág. 8: configuração das teclas capsense     |
| (NL) Pag. 8: capsense-toetsen configureren    |   |

DIP S2				Art. (6700W / 6700W/BM / 6701W / 6701W/BM ) + Art. 6733W Art. 6701B / 6701B/BM						
DIP 1	DIP 2	DIP 3	DIP 4	P1	P2		P3	P4	P5	P6
0	0	1	1	INTb	AI		INT	ACT	D	CCS

- |  |  |
|--|--|
| (IT) Pag. 12: programmazioni pulsanti per chiamata intercomunicante  | (DE) Seite 12: tastenprogrammierung für Interngespräch                     |
| (EN) Page 12: programming buttons for intercom call                  | (ES) Pág. 12: programación de los pulsadores para llamada intercomunicante |
| (FR) Page 12 : programmation des boutons pour appel intercommunicant | (PT) Pág. 12: programação dos botões para a chamada de intercomunicação    |
| (NL) Pag. 12: programmeren drukknoppen voor intercomoproep           |  |

DIP S2				Art. (6700W / 6700W/BM / 6701W / 6701W/BM ) + Art. 6733W Art. 6701B / 6701B/BM						
DIP 1	DIP 2	DIP 3	DIP 4	P1	P2		P3	P4	P5	P6
0	0	1	1	INTb			INT			

- |  |   |
|--|---|
| (IT) Pag. 14: programmazioni pulsanti per altre funzioni         | (DE) Seite 14: tastenprogrammierung für andere Funktionen         |
| (EN) Page 14: programming buttons for other functions            | (ES) Pág. 14: programación de los pulsadores para otras funciones |
| (FR) Page 14 : programmation des boutons pour d'autres fonctions | (PT) Pág. 14: programação dos botões para outras funções          |
| (NL) Pag. 14: programmering drukknoppen voor andere functies     |   |

DIP S2				Art. (6700W / 6700W/BM / 6701W / 6701W/BM ) + Art. 6733W Art. 6701B / 6701B/BM						
DIP 1	DIP 2	DIP 3	DIP 4	P1	P2		P3	P4	P5	P6
0	0	1	1		AI				D	CCS



1ª edizione 04/2015  
 8 023903 301571 cod. 2G40001365

